




Assembly Guide

E21200 - SAY A



2018.06

First check the contents to make sure that nothing is missing. Sort out the screws and fittings as shown.
Assemble your furniture step by step, as shown in the illustrations.



Assesories E21250 (Additional buy)




1 x R
E9950060





2 x S
E99000068





2 x T
E9910013














Adjust
Angle* on sign holders
by loosen the bolts and
reposition the sign holders

